

LA GRANGE FARMHOUSE - CHANGING THE GAS BOTTLE

PLEASE LET US KNOW IF A GAS BOTTLE IS EMPTY SO WE CAN REPLACE IT AS SOON AS POSSIBLE AND AVOID BOTH BOTTLES RUNNING OUT.

If the gas runs out for the hob in the kitchen then a new bottle can be switched on as follows:

Step 1.

In the outside gas cupboard on the kitchen terrace are two gas bottles. If the gas runs out you can switch to the other gas bottle by rotating the white plastic switch 180 degrees – the arrow on the dial will then point to the new gas bottle.



Now check that the tap on the top of the new gas bottle is open. There are two letters with a double ended arrow "O" (ouvert/open) and "F" (ferme/shut). Make sure that the tap is fully rotated in the direction of the "O."

Step 2.

There is a further tap in the kitchen that needs to be rotated once the gas supply has been changed. This is located at the back of the four-drawer unit immediately to the right of the cooker.

Pull the drawer out fully and then gently lift the drawer away from its runners. **Please do not force this process as it could damage the runners.** Place the drawer to one side and then you can move on to step 3.



Step 3.

The white switch will “fail safe” if there is no gas supply and the red bar on the switch will be horizontal indicating that the gas has been isolated.



To allow the gas to flow again rotate the red bar through 90 degrees.



Step 4.

Check the gas is reaching the hob. Replace the drawer by ensuring the runners are fully extend then position the drawer on the runners and gently close the drawer which should click the drawer into position. **Please do not force this process as it could damage the runners.**

If there is still no gas supply then contact Tracey for further help.

PLEASE LET US KNOW IF A GAS BOTTLE IS EMPTY SO WE CAN REPLACE IT AS SOON AS POSSIBLE AND AVOID BOTH BOTTLES RUNNING OUT.